封面

APEX
VR70 V4.0

01 Precautions
02 Standard accessories
Names of various components of the aircraft
03-05 Battery installation of the remote control
Frequency synchronization and calibration between the remote control and the aircraft
Function Description of the remote control
The correct operation method of the aircraft
Replace the propeller
06-08 Charging of aircraft
Beginner's flight adjustment and precautions
Quick Start Guide
09-16 Connecting and Operating Head-Tracking Motion Control
Usage method of the simulator
This product can also be operated with a universal remote control
Connection method
VR Introduction
Remote Control Function Description
How to troubleshoot situations during flight

User Manual

Important Statement

1. This product is suitable for teenagers and adults aged 14 and above. This remote-controlled quadcopter has certain difficulties in the initial learning stage and needs to fly under the guidance of personnel with operational experience.
2. This product is produced by integrating high-tech from multiple aspects such as electronics and mechanics. For those with insufficient operation experience, it is essential to stay away from people during flight. Improper operation may cause serious personal injury or property damage, for which we assume no responsibility.
3. Once the product is sold, we will not be held responsible for any safety incidents such as accidents that occur during operation or use.
4. If you encounter any unresolved to use, operation or maintenance, you can contact the local dealer for technical support or aftersales service.

Note : 1. Please make sure to check the surrounding environment before flying.
2. Do not let the aircraft fly out of sight when it is in flight.
3. Children are not allowed to fly alone. Please fly with an adult.
4. Please confirm that there are no other products using the same frequency band nearby before flying it in the same area.

Warning

*The charger, wires, plugs, casing and other components should be inspected regularly. If any damage is found, use should be stopped immediately until they are repaired properly.
*Please use the charger provided by the manufacturer. Please check whether the charger is in appropriate voltage. And switch to the appropriate gear according to the battery voltage.
*Please clean this product with a clean and soft cloth. Before cleaning, the aircraft should be turned off and the battery removed.
*When charging rechargeable batteries, adult supervision is required. Non-rechargeable batteries cannot be recharged.
*Do not disassemble, crush, puncture, drop the battery from a height or throw it into fire.
*If the product is not operated for a long time, please remove the battery.
*Do not severely strike or drop the aircraft and the remote control.
*Please keep the user instruction manual contains important information about the product. Please keep them.

Do not allow the aircraft to fly in the following places

Standard accessories

Names of Drone Components



No	Name	Quantity
1	Reverse propeller	2
2	Forward propelling propeller	2
3	Upper shell	1
4	Battery shell	1
5	CCW motor	2
6	CW motor	2
7	Lithium battery	1
8	Receiving board	1
9	Camera	1
10	Cover plate	1
11	Damper	4

Remote Control Function Description



Remote Controller and Aircraft Binding & Calibration

Step One

First, turn on the power switch of the remote controller, then connect the aircraft to the battery. Position the aircraft on a flat surface with its tail facing the operator. The remote controller will emit a "beep" indicating that the aircraft's indication light will stay solid, indicating that the binding has been successfully completed.
Re-matching: If the code cannot be matched, shake the aircraft. Wait for the seven-color light to flash in a loop, then long press the code reset button. The remote control will re-match the aircraft.

Important note: Connect the aircraft to the power supply. Since the gyroscope inside the aircraft needs to be initialized upon being opened, it is necessary to ensure that the ground where it is placed is a static horizontal plane.

Function Description of the remote control

1. Power on/Off
① To power on, press and hold the remote controller's power button until it enters working mode.
② To power off, press and hold the remote controller power button until the power indicators lights turn off, and the remote controller enters shutdown mode.
3. Stopping the motors
In Standby Mode, short-press the "Fn" function button to activate motor idle speed.
Press the "Fn" button again to stop the motors.
While flying, short-pressing the "Fn" button will initiate a slow descent and lock the aircraft.

Beginners are recommended to fly in a wide area before entering the simulator. Users can familiarize themselves with the flight control functions of the aircraft in the simulator before then press the unlock button to unlock.

5. Throttle control
After unlocking, push the throttle stick above the center position to make the aircraft ascend.
Pull the throttle stick below the center position to make the aircraft descend.
When the throttle stick is at the center position, the aircraft will maintain its current altitude (Altitude Hold Mode)
6. Flying forward/backward (pitch)
Using press and hold the code matching key to exit the channel that matches the aircraft. When the aircraft is not coded, after powering on, shake it until the seven-color light flashes, then turn on the remote control. The aircraft will enter the matching state by itself.
5.3 learning (yaw): After the aircraft takes off, the throttle joystick moves leftt/right, causing the aircraft to turn left/right.
6. Flying forward/backward (pitch): After the aircraft takes off, the direction joystick swings forward/backward, and the aircraft flies forward/backward.
7. Left and right bird (roll sideways): After the aircraft takes off, the direction joystick is shaken left/right, and the aircraft flies left/right.
8. Free-turning function (Fn+Direction joystick combination key)
After the aircraft takes off, if it drifts in one direction without joystick input, use the FN function button in combination with the direction joystick to fine-tune the aircraft's flight (to achieve a stable hover.(Hold down the Fn button while using the direction joystick for fine adjustments.)
9. Screw-color light combination
10. Speed gear switching (optional): The aircraft's color lights will cycle and change colors in the order of red, orange, yellow, green, cyan, blue and purple.
10. Short press to switch speed/long press to talk
Mode switching: Press briefly to switch between 3 flight modes. There are a total of 3 Settings. The first setting is when the buzzer sounds, which is the minimum speed, two sounds indicate the second gear, three sounds indicate the third gear and the maximum speed. Then press to switch to 1 gear in a loop. When the throttle is not at the center, the aircraft will fly in the corresponding direction at the speed of the gear. If the aircraft is left for a long time. When the direction joystick is turned, the aircraft will roll 360 degrees in the corresponding direction. (One-click rolling is only available in the fixed-height mode.)
Mode switching: Press briefly to switch between 3 flight modes. There are a total of 3 gears. When the buzzer sounds once, it is the self-stabilizing high mode, two sounds indicate semi-self-stabilizing mode, and three sounds indicate the low mode (beginner).
Self-Stabilizing Altitude Mode (In Altitude Hold Mode, when flying in Speed Level 1 or 2, the drone activates the Optical Flow Positioning function for stable hovering in Speed Level 3 only Altitude Hold is available, and Optical Flow is not activated.)
Semi-Stabilized Mode (In this mode, the aircraft does not support altitude hold or automatic hovering. The pilot must manually control the throttle and direction sticks to maintain altitude and position.)
11. Gyroscope calibration: Place the aircraft on a flat surface, turn on the power, and start using the joystick. When flying forward, back-ward, left, or right, the aircraft will maintain its attitude after stick input and continue flying in that direction automatically. Throttle (ascend/descend) and yaw (rotation) are not affected.
12. Calibration joystick
In an unbound state after powering on, center both joysticks completely. Then press and hold the Fn button. The aircraft's LED light will flash rapidly, indicating that it has entered the gyroscope calibration. Once the flashing stops, release the buttons. Next, move both joysticks in smooth circular motions from the center to the outer edges. The aircraft's LED light will turn solid, indicating that the remote controller has entered the matching mode. Finally, the aircraft will automatically exit the calibration mode. Note: Calibration is mandatory. Failure to do so may result in issues such as inability to unlock or take off.
13. Headless mode
When the drone overturns, press and hold the LED light key without releasing it to enter the anti-turtle mode, and the drone indicator light will flash. At this point, push the front, back, left and right joysticks until the drone turns back to the front, and then release the LED light keys.

14.APEX VR product can both be operated in V2.4G support
Note: The VR glasses support 48 channels, function button and the power button simultaneously to switch between APEX FX and EURS 2.4G protocols.
Four ball beads indicate the APEX FX protocol; four slow beeps indicate the built-in high-frequency EURS 2.4G protocol.
15.FPV simulator practice
Turn off the remote control. Connect the remote control to the PC computer with a Type-C data cable. Launch the simulator software. Select the aircraft model and channel mapping. Enter the flight performance FPV simulator. (Supports mobile devices such as mobile phones and tablets. Please note that an OTG adapter is required.) The connection method using an audio cable and a dongle is also acceptable. Note: The VR glasses can be connected to the simulator software via a Type-C data cable or audio cables. The one with the aircraft code matching will automatically be confirmed as coach mode, and the other will be student mode.
16.Coach mode: In the coach and constant-altitude mode, when Fn+ throttle joystick is pulled down, the aircraft will come to an emergency stop directly.
18.5 switch channels in a preset manner: Press Fn+ Speed Switch key to enter the linked switching of video transmission channels. Each press will switch channels once.

Note: When changing the battery of the aircraft, the remote control does not need to be restarted for code matching. Using press the Fn key + code matching key on the remote control.

The correct control method of the aircraft

Please simulate the flight proficiently in advance before the flight



Remote control Charging Instructions



Charging of aircraft

1.Connect the USB charging cable to the charging case and the adapter. After turning on the power,r ensure the battery from the plane and plug it into the charging case.
2.When the battery is connected correctly, and the battery is charging. When the battery reaches saturation, the light will automatically turn off.

Charge with the dedicated charger we deliver

Note: During the flight, the remote control makes a "whoosh whoosh..." sound. When the sound is heard, it indicates that the battery voltage of the aircraft is insufficient. After landing, charge it.

Rechargeable battery

This quadcopter uses rechargeable lithium batteries. If the battery cannot be recharged repeatedly, please handle it properly in accordance with local handling regulations.

Remote control battery

■ The remote control requires two "AAA" batteries (not matched). Please read the following important notes before using them.
■ Do not mix with alkali, standard (carbon-zinc) and rechargeable batteries (nickel-metal-hydride).
■ Do not use new and old batteries together.
■ Do not use rechargeable batteries are prohibited.
■ Rechargeable batteries should be removed from the remote control before charging (if removable).
■ Non-rechargeable batteries can only be used under adult supervision.
■ When the battery is exhausted, it should be disassembled immediately and must be properly recycled or disposed of in accordance with national or local government laws and regulations.
■ Check that the supply terminal should not short-circuit.
■ Do not throw the battery into the fire as it may cause leakage or explosion.
■ Battery should be installed according to the correct polarity (refer to the internal manual).

Beginner's flight adjustment and precautions

Note
■ Please confirm whether the battery is installed properly and whether the propeller is stable.
■ Confirm whether the battery power of the remote control and the aircraft is sufficient.
■ Confirm again that the rotation direction of the propellers is in a manner corresponding assembly position.
■ When flying over long distances, please extend the antenna of the remote control.

Beginner's flight adjustment and precautions

1. Throttle control practice

Note
■ Confirm that there are no other people or obstacles in the flight area.
■ Do not fly in the direction of people to avoid injury caused by the rotation of flight movements (hovering the aircraft remains in the air and maintains a fixed position).
■ When practicing, please stand at least 2 meters behind the aircraft.

The throttle control is in the up and down direction of the left hand. Slowly push the throttle joystick upward, and the aircraft will take off and fly to a height of about 1.5 meters above the ground. Pull the joystick down slowly and release it immediately. The aircraft will descend and remain at a fixed height. Slowly push the throttle joystick down to land the aircraft to any height and then it can descend exactly to the ground.

2.Practice of front-back and left-right control

1.Practice front and back. The front and back are in the up and down direction of the right hand. First, keep the aircraft at a height of 1.5 meters above the ground. Push the joystick up when the aircraft is stable, move back by one meter. Repeat the practice.
2.Practice the right side flight practice. The left and right side flights are in the left and right directions on the right hand, the method is the same as above.

Attention

When the aircraft is in a remote area, please lower the throttle and land the aircraft, then walk 2 meters away from the aircraft to restart the self-test and continue practicing. Or move back to the original position and continue practicing.

3.Rotation operation practice

Slowly raise the throttle lever to control the aircraft to a certain height. Then slowly push the left-right joystick to the left/right to make the aircraft rotate counterclockwise/clockwise slowly.

4.Precision practice

When you feel familiar with the movements in steps 1 to 3, draw a circle on the ground and practice flying within the range of this circle to increase the accuracy of your control.
Once you are more accustomed to the operation actions, you can draw smaller circles.

5.Change the direction of the aircraft

When you feel familiar with the movements in steps 1-4, stand on the side facing the aircraft and continue practicing steps 1-4. After that, stand in front of the aircraft and repeat the steps for practice.

6.Free-wing of flight actions

In the non-head point mode (self-stabilizing high mode, three-speed mode or semi-self-mode) Slowly push the throttle lever to the left/right and leave the ground, if the aircraft leans heavily to one side, it will drift in the direction of the aircraft. Use the control joystick to correct it.

1.After the aircraft takes off, it gradually inflects in the forward/backward direction. At this time, you can hold down the Fn key (at the same time as the left/right joystick) to keep the aircraft flying. When moving forward, adjust the direction joystick downward. when moving backward, adjust the direction joystick upward. When adjusting to the left, adjust the direction joystick to the left. When shifting to the right, adjust the direction joystick to the right.

2.After the aircraft takes off, it gradually inflects in the left/right direction. At this time, you can hold down the Fn key (at the same time as the left/right joystick) to keep the aircraft flying. When moving forward, adjust the direction joystick to the left. When shifting to the left, adjust the direction joystick to the right.

Quick Start Guide



Head-tracking body-sensing connection Method 4.0

1.First, turn on the VR glasses and place them on a horizontal surface, then turn on the remote control.
2.Turn on the drone, use the mode switch key to enter the head-chasing mode. Briefly press the reset code alignment key to calibrate the VR glasses. During calibration, the indicator light on the remote control will flash quickly. After calibration is completed, the remote control will make a long beep. If the VR glasses keep flashing rapidly, it indicates that the calibration has not passed. Press and hold the Fn+ mode switch key again to exit the head chase mode.

Note1

1.Head-chasing control: VR glasses need stable control and should be kept as level as possible.
2.When operating the forward and backward tilting or left and right rotation, try to control it slowly and evenly to avoid overturning due to excessive movement of the drone. After becoming proficient in the operation, gradually increase the speed and amplitude.

Head-chasing body-sensing Control Method 4.0

Please simulate the flight proficiently in advance before the flight



Notice Long time use of head chasing function may lead to dizziness, please gradually adapt, pay attention to rest!

Connection method

Drones – Connected to other glasses, conditions and methods:

1. Drones can be connected to 5G and can be directly used with a 5.8G VR goggles after frequency pairing. As long as the frequency matches (e.g., 5880, 5860, etc.), it can be used.
Install the antenna properly: If you want to record videos, please install the SD card in advance. Currently, only SD cards with a capacity of 32G or less are supported.

The remote control has the function of connecting to a computer to simulate operations.?
No connection method after downloading the simulator game.?

1.The remote control doesn't power on.
2. Prepare an otg adapter and connect the type-C data cable to the adapter.
3. Connect the Type-C data cable port to the remote control, and connect the otg adapter to the computer's USB port. When the controller light stays on, the connection is successful. Open the simulator software, calibrate the joystick, and start your FPV training.

Note1 Apple systems are not supported. Computers with Windows 7 or lower systems are not supported. The emulator and practice tutorials can be obtained for free by contacting customer service.
Note2 Whether the adapter is connected to the mobile phone, and whether it is an Apple or Huawei user

Firmware upgrade

1.Software download (This APP is also used for:
Android mobile phone): https://www.pgyer.com/Hm9QBEKn

For Iphone: Search for "Apex Flight" in the App store to download it
2. Connection Method:
Turn on the remote controller without binding it. Open the Apex-Flight app, tap the Bluetooth connection in the top right corner, and select the name of the VR. Tap the connection button of this name to establish a connection, and the remote controller will connect successfully.
3.Upgrade method: Click the Settings icon in the upper right corner, click Firmware Upgrade, and follow the prompts to complete the upgrade.
4.After the upgrade is successful, just calibrate the joystick.

Note
1. The new remote control does not require an upgrade
2. JP = Japanese-style controller, TX = American-style controller.
3. The APP version number must be consistent with the remote control or the mobile phone.
Make sure the device is fully charged. If the power is interrupted, the upgrade will fail and the device may not function properly.
4.If the upgrade is incorrect, please reupgrade the firmware. If it becomes brick, it needs to be returned to the factory for repair.
5.Please calibrate correctly; otherwise, situations such as inability to unlock or take off may occur

This product can also be operated with a universal remote control

How to connect other brand remotes
1. Purchase a universal 2.4G remote control corresponding to the CRSF protocol.
2. Remove the 4-pin ribbon cable that comes with the receiver.
3. Find a suitable one from three screws on the canopy and open the canopy.
4. Insert the 4-pin ribbon cable into the receiver.
5. Route the cable through the cable outlet.
6. Secure the connection cables neatly from the rear of the canopy, install the canopy properly, and tighten the screws.
7. Bind the universal remote control to the receiver. Once the aircraft, open the remote control function page, and connect to the receiver (successfully connect the 2.4G universal remote control).

Note: This product supports up to 8 channels.

Pay special attention
4. When purchasing a universal remote control, a receiver is required.
5. The 4-pin ribbon cables of the receiver need to be inserted into the VR receiver.
6. The universal remote control purchased is 2.4G and comes with the CRSF protocol.

Introduction to VR

1-1、VR

1-2. Charging status & Working state

1-3、Specifications

Screen Size	3 inch
Screen Type	TFT LCD
Resolution	360(W)×640 pixels
Brightness	320cd/m2
Sensitivity	-90dBm
Channel	48 channels
Dimension	110.4*138.8*83.5 (mm)

1-4、DISPLAY&BUTTONS

2、CAMERA

2-1、CCHANNELS

Channel change



Channel List

	CH1	CH2	CH3	CH4	CH5	CH6	CH7	CH8
1	172	172	1000	1000	172	1000	1000	1000
2	172	172	1000	1000	1000	1000	1000	1000
3	172	172	1000	1000	1000	1000	1000	1000
4	172	172	1000	1000	1000	1000	1000	1000
5	172	172	1000	1000	1000	1000	1000	1000
6	172	172	1000	1000	1000	1000	1000	1000
7	172	172	1000	1000	1000	1000	1000	1000
8	172	172	1000	1000	1000	1000	1000	1000
9	172	172	1000	1000	1000	1000	1000	1000
10	172	172	1000	1000	1000	1000	1000	1000

Note: The VR glasses support 48 channels, while the aircraft only supports gray

2-2、Video mode/photo mode switching

OSD display



2-3、VIDEO

2-4、Photo album

3. ALBUM

3-1、VIDEOS AND PHOTOS



4.SETTINGS

Click M key, menu show/hide

Replace the propeller

In order to achieve the best flight performance, the propeller needs to be inspected or replaced with a new one after multiple flights. Especially after a hard landing or collision during the flight, the propeller may be damaged.
1.This aircraft has four propellers.
2.When replacing the propeller, please ensure that the indicator letters on the propeller match the letters on the aircraft. For example, the letter A represents a counterclockwise propeller, and the letters are on the front of the propeller.
3.Special attention should be paid to replacing the damaged propeller with a propeller that turns correctly. Never change the propeller with the wrong direction!

How to troubleshoot situations during flight

	Troubles	Causes	Solutions
1	Turn on the drone, LED blinks	Pair between drone and controller failed	(please refer to the frequency alignment of remote control and drone reverse in FPV)
2	Turn on the drone, the drone has no reaction to the commands	The battery died	Charge the drone
3	Blades keep moving after landing	Throttle lever is not at the zero position	Put the throttle lever to zero position
4	Blades keep moving while the drone can't not take off	1. Blades may installed wrong 2.No 8-nough power	1. Change the blades 2. Charge the drone
5	After trimming, drone can't fly straight, the speed of blades is different	1. Blades may installed wrong 2. Blades get damaged 3. Calibration failed	1. Install the blades correctly 2. Replace blades 3.Refer to p5 for calibration
6	The drone can not take off	1. Blades are getting lose 2. Blades get Damaged	1. Tighten the blades 2. Replace the blades

FACEBOOK YOUTUBE

Email:intlsarshakilyla50@gmail.com

Made in China

IM-VR70(4.0)-EN-01

封底

材质：128g双铜
Size:138*210mm